


Built-in help mode

1. Click the help icon to enable the help mode (see 1 on image).
2. The overall help instructions appear; read and close.
3. The help mode is now active. Most items throughout the hub will display a yellow help box which explains its functionality (see 2 on image).
4. Click the help icon again, the help mode is now deactivated.

The help texts are dynamic and based on the functionality used in the fault tracing at hand.



Note: Toggle the help mode on with the Question-mark icon (see 1 on image).